

# BYKECAM™ Monitor Adjustments

Thank you for your recent purchase of BYKECAM

Charge the battery completely using the included charger before using BYKECAM™

## Brightness adjustment

1. Push the center button one time on back of monitor (while monitor is on)
2. You will see brightness slider on the screen
3. Pushing the right button will decrease the brightness
4. Pushing the left button will increase the brightness

## Contrast adjustment

1. Push the center button two times on back of monitor (while monitor is on)
2. You will see the contrast slider on the screen
3. Pushing the right button will decrease the contrast
4. Pushing the left button will increase the contrast


## Saturation adjustment

1. Push the center button three times on back of monitor (while monitor is on)
2. You will see saturation slider on the screen
3. Pushing the right button will decrease the saturation
4. Pushing the left button will increase the saturation

## Tint adjustment

1. Push the center button four times on back of monitor (while monitor is on)
2. You will see Tint slider on the screen
3. Pushing the right button will decrease the Tint
4. Pushing the left button will increase the Tint

Scan QR code to BYKECAM.com website click on installation link



Please register your BYKECAM products with the enclosed serial number on the product registration page at [WWW.BYKECAM.com](http://WWW.BYKECAM.com)

SAMPLE SERIAL NUMBER



